


## SAFETY ON THE CONSTRUCTION SITE

**EVEN WITH LONGER END HOSES** 





## Easy on-site installation


- 1. Fold the last boom segment before concreting
- 2. Open the coupling on the last elbow hinge
- 3. Rotate the elbow by 90° the concrete will flow from here directly into the end hose instead of the pipeline for the last arm segment
- Install the special end hose extension bracket and secure it in place with both couplings
- 5. Attach the extended end hose (the maximum load of 350 kg incl. concrete must not be exceeded)
- 6. Attach the end hose safety cable
- 7. Attach the protective sleeve to the couplings (depending on the end hose configuration)



## Putzmeister genuine parts – available from your Putzmeister service partner

■ For elbows with 180 mm radius: **AN 694524** 15.3 kg

■ For elbows with 275 mm radius: **AN 680339** 17.8 kg









## **Putzmeister Concrete Pumps GmbH**

Max-Eyth-Straße 10 · 72631 Aichtal/Germany Tel. +49 (7127) 599-0 · Fax +49 (7127) 599-520 pmw@putzmeister.com · www.putzmeister.com